

# DIY

with

## INROADS

credit union

### DIY Wood Slat Door Mat by Shannon Quimby

#### MATERIALS

- 3 1"x1"x12" Cedar boards
- 12' 3/16" braided nylon rope
- 64 5/16-18 hex nuts
- Wood stain
- Wood polish or wax
- Foam brush
- Rags
- Miter saw
- Hand sander
- 150 grit sandpaper
- Drill
- 9/32" drill bit
- Tape measure
- Painters tape
- Scissors
- Sharpie



